



S2 HEVC 4K Video Encoder

USER MANUAL


KILOVIEW Electronics CO., LTD



Legal Notices

Subject to the receiving of this document from Changsha Kiloview Electronics Co., Ltd., (Hereinafter referred to "Kiloview"), the following terms are understood and agreed. Or else, please stop using this document.

This document is copyright of Kiloview, all rights reserved. The document covers the proprietary information of the company. No company or individual may copy, transmit, distribute, use or disclose the document and any images, forms, data and other information contained in the document without the prior written permission of the company.

 *is the registered trademark of Kiloview. The name and logo are the trademarks or registered trademarks of the company. Other products or company names mentioned in this document may be the trademarks or registered trademarks of their respective owners. The reading of this document without the prior written consent of the company or the third-party rights holder does not imply that the reader is given any right to use any of the marks appearing in this document by implication, non-evidence or otherwise.*

This product complies with the design requirements related to environmental protection and personal safety. The storage, usage and disposal of the product shall be in accordance with the product manual, relevant contract or relevant national laws and regulations.

This document is provided "as is" and "only in this state". Products and technical updates are subject to change without prior notice.

For matters not covered in this document, please visit our website www.kiloview.com for information and technical support.



CONTENTS

1. Product Introduction	1
1.1 Advantages	1
1.2 Parameters	2
2 Operation Guidance	错误!未定义书签。
3 Device Interface Description	错误!未定义书签。
3.1 Device Interface Description.....	3
3.2 Signal Indicator Light	5
4 Installation And Connection.....	6
4.1 Video Signal Connection.....	6
4.2 Network Connection.....	6
4.3 Power Connection	7
5 Login And Network Configuration.....	8
5.1 Device Login	8
5.2 Network Configuration.....	8
5.2.1 Ethernet.....	8
5.2.2 Advanced Setting.....	10
6 Function Parameter Configuration.....	错误!未定义书签。
6.1 Status Column.....	11
6.2 Audio & Video Encoding Setting.....	12
6.2.1 Audio And Video Signal Source Setting.....	12
6.2.2 Video Encoding Parameter	13
6.2.3 Audio Encoding Parameter.....	15



6.3 Text And OSD Overlay.....	17
6.3.1 Text Overlay.....	17
6.3.2 OSD Overlay.....	18
6.4Color Adjustment.....	20
6.5 Image And Rotation.....	20
6.5.1 Horizontal Mirror	20
6.5.2 Vertical Flip.....	20
6.2.3 Flip.....	21
6.5 Video Cropping	21
6.6 Serial port And PTZ.....	23
6.6.1 USB Expansion Port.....	23
6.6.2 PTZ Setting.....	23
6.6.3 Control Panel	24
6.6 Local Recording.....	25
6.7 NAS Storage	28
7 Streaming Service.....	错误!未定义书签。
7.1 NDI HX.....	30
7.2 NDI Discovery Server	31
7.3 RTSP.....	33
7.4 SRT	34
7.5 RTMP Pushing(Live Streaming).....	37
7.6 TS-UDP Pushing (Unicast And Multicast).....	38
7.7 HLS Streaming	40



8 User Management.....	41
9 Location & Time Management.....	41
10 System Setup.....	错误!未定义书签。
10.1 Language.....	42
10.2 Restore	42
10.3 Reboot.....	42
10.4 Firmware Upgrade	43



1. Product Introduction

S2 is an UHD 4K HDMI video encoder, which supports up to 4Kp60 input and H.265 (HEVC)/H.264 high-performance encoding with Gigabit wired network transmission. Also, it supports the most common protocols including NDI|HX/SRT/RTMP/RTMPS/HLS/UDP/RTSP, etc.



1.1 Advantages

✧ **UHD and low latency**

- With H.265 HEVC encoding, S2 realizes lower encoding bitrate and save more than 40% bandwidth comparing with H.264.
- Support 1000Mbps Ethernet port (with PoE).
- Low encoding latency less than 34ms.
- Resolution up to 4KP60Hz input supported.
- Support voice intercom (Workable with the deployment of intercom server)



1.2 Parameters

Model	S2
HDMI input	HDMI 2.0
Analog audio interface	1*3.5mm Line in
USB interface	USB2.0
Video interface	1 channel HDMI input, 1 channel HDMI loop
Network	1000M Ethernet
POE	Support
Streaming protocols	NDI HX/SRT/RTMP/HLS/TS-UDP
Video resolution input	Up to 4KP60
Video encoding	H.264/H.265
Encoding resolution	4KP30
Audio encoding	AAC/G7.11
Management method	Web management
Power	DC 12V/1A
Working temperature	-20°C~60°C



2. Operation Guidance

- **Installation and connection**


Connect the power, Ethernet cable and video input source correctly, power on the device.



- **Network connection and configuration**

The simplest way is to access the unit via Ethernet through default IP address (192.168.1.168) to login the WEB page for setting (default username and password: **admin/admin**).

3. Device Interface Description

3.1 Device interface description








1. Tally	2. Status Indicator	3. Power Switch	4. Power Port
5. 3.5mm Line In/Line Out	6. HDMI Loop	7. HDMI Input	8. USB Expansion Port



9. GbE port with PoE	10. Reset		
----------------------	-----------	--	--

3.2 Signal indicator light


Name	Color	Status	Description
POWER 	White	Always on	Power connected
		Flashing	Power off or failure
		Off	No power supplied or power failure
LINK 	White	Quick flashing	Network connected
		Slow flashing	Network connection abnormal or restore factory setting indication (Run light will be flashing as well)
		Off	Network disconnected or abnormal
RUN 	White	Flashing	Working normally
		Always on	Indication for device restore factory (Link light will be flashing as well)
		Off	Working abnormal or not start



4. Installation and Connection


4.1 Video signal connection

Connect HDMI signal from a source (such as camera) to the device HDMI port through a cable.




4.2 Network connection

Connect the network cable to Ethernet port, and connect the other end to the network switch or directly to the network port of the computer.



4.3 Power Connection

Using the power adapter (DC 12v) to connect to the power connector of the device. Turn on power switch, the power light will be on and the device starts working, which will take 30~40s.



Note: If your switch supports POE power supply, there is no need to connect to the power supply.



5. Login and Network Configuration

5.1 Device login

1. The default management IP address for the device:

The default management IP address of the encoder is 192.168.1.16, which could be used as device management all the time and no effects on the device business IP address. Net mask is 255.255.255.0.

2. Computer network configuration

Click “network and Internet setting” -- “Network and sharing centers” — “Ethernet” — “Internet agreement version 4” —Use below IP address, enter 192.168.1.* manually (* refers to the number from 1 to 255 besides 168) and net mask, click “Login” .

3. WEB management page login

Open the WEB browser, enter 192.168.1.168 in the URL. Fill the username and password in the login interface. Both default username and password are admin.



Note: Due to the browser compatibility issues, it may cause the webpage display abnormal, it is recommended to use Chrome and Firefox.


5.2 Network configuration

5.2.1 Ethernet

After login, you could configure internet IP by DHCP or manually (Default is



DHCP). This IP address could be used for network streaming and device management. After configured IP address, you could directly visit this IP address to login to the device.



There are two ways to get the address, one is DHCP, and the other is manually. To use DHCP, please ensure that the router or switch has enabled the DHCP service. This method is simple and convenient, but the IP obtained by DHCP changes continuously, and you cannot directly know what IP address the encoder gets. To select manually, you need to enter a fixed IP to the device, and this IP address is fixed as long as the device does not restore the factory settings, this method is more stable. Therefore, the two methods have their own advantages, and can be selected accordingly.



5.2.2 Advanced setting

HTTP/HTTPS setting

The default web service port is 80 (https port is 443). You can change it (range: 1-65535) accordingly. After revised corresponded port, visit device configuration page. You need to add the changed port behind the device IP address before you visit. For example, the device normal login IP address is 192.168.1.168, change Web service port from 80 to 90, HTTPS service port from 443 to 450, then enter 192.168.1.168:90 or <https://192.168.1.168:450> to visit device respectively.

By HTTPS, if the web browser prompts certificate errors which is caused by the browser certificate security authentication, you will need to add it to the safe list of the browser.

Local-link (Failsafe)

Enabled Status ON

IP 192.168.1.131 Net mask 255.255.255.0 Gateway Please Enter

Apply

Routing strategy



The routing strategy is for routing release and reception. Its operation object is data package. According to the needs, the data packet transmission path can be changed according to a certain strategy. When the device is connected to multiple network links, the different data link can be sent according to the appointed network link through designated strategy, which improves the utilization efficiency of the link.




Note: It is required that professional person with knowledge of the current network routing table or network to operate routing strategy. Incorrect configuration may cause device abnormal.

6. Parameter Configuration

6.1 Status column

In the status column, the left window is for preview of the video source either with image or video. When preview with image, you will see image stream, which refresh every 3 seconds. When preview with video, you will see smooth video. You can control and switch image stream and video stream through the switch button. If the preview window is displayed in black, it means the video source has not been detected by the device, and you need to check whether the input cable is plugged in correctly. The icon  and  in the lower left corner of the preview window can realize the functions of safety frame and center line for the preview video.




The parameters for main stream and sub stream are showed at the right window. You can switch the pages through clicking main stream and sub stream in the upper left corner. Brief introduction of the relevant encoding parameters as below:



- Video source: Display the interface of the source
- Encoding format: Display the encoding format of the source
- Resolution: Display encoding resolution of the source
- Real time bit-rate: Display real-time encoding bit-rate changes of signal source.
- Network flow: Display the real-time consumption flow changes of signal.
- Audio source: Display audio format of the signal source
- Memory usage: Status of content usage
- Storage space: The usage status of internal storage space
- CPU: The usage status of CPU

6.2 Audio and video encoding setting

Click setting button in the status column, enter to “audio and video encoding setting” interface.




6.2.1 Audio and video signal source setting

There is only one HDMI input for the device, video source defaults to HDMI. For




audio source, you can select HDMI embedded audio or analog Line in. Default setting is HDMI embedded audio.



6.2.2 Video encoding parameter

Main streaming encoding parameters setting parameter as below:



- Two ways of encoding mode, the main stream and sub stream can be selected as H264 or H265.

- “Scaling” has 7 options for choice. Default setting is “Default size” , that is, the video size after encoding is the same as the input video size. You can also set to encode low resolution input into high resolution output, and similarity, high resolution input can be encoded into low resolution output.

- “Color” has two options: “With color” and “monochrome” .



Monochrome is black and white color, “with color” remains the original color.

Default setting is “With color” .

- “Profile” supports High profile, main profile, baseline, which is set according to platform supported encoding profile. High Profile is the highest compression efficiency, that is, under the same bit-rate, image quality is the best; Baseline is the most widely supported; default setting is High Profile, which should be based on the actual platform supported (Only one profile for H.265 encoding).
- “Bit-rate control” has two ways: CBR (Constant bit-rate) and VBR (Variable Bit-rate). From literal meaning, CBR is stable and unchanged bit-rate, while VBR is constantly changing according to actual content. Generally, network transmission adopts CBR to guarantee transmission quality, while file storage uses VBR to guarantee file quality. Default setting is CBR-Constant bit-rate.
- “Bit-rate” supports adjustable 20K-40M. You can select as we set or self-define bit rate. Theoretically, the higher bit-rates, video quality after encoding is better. But specific setting should be based on actual network situation, and couldn’ t be higher than your own upstream bandwidth.
- “Framerate” support adjustable from 1FPS to 60FPS and customized framerate, customized framerate is user assigning framerate manually after encoding, in theory, it shouldn’ t be higher than original framerate.
- “GOP size” has seven options and supports user-defined adjustment. GOP (Group of Pictures) is a group of consecutive picture, the strategy of GOP affects encoding quality. It is adjustable according to actual situation, default is




60, and normally it could meet the most majority of needs.

6.2.3 Audio encoding parameter

Audio encoding modes include AAC and G.711 for choice. Audio sampling is chosen according to actual situation. Audio channels consist of “Stereo” and “Mono” . Encoding bit-rate is adjustable between 16K-512K, default is 64Kbps.

The input channel supports 4 audio channels input. You can select two channels for encoding output and add, delete, modify audio channels according to your needs. Each pair audio channel can be set as different encoding mode, sampling and mapping relationship between input channel.

1) You had better to create 4 audio channels, click “+” and new audio channel created.



2) Set audio name, encoding mode, sampling and mapping relationship between input channels.



Audio encoding settings

* Name	
Encode	AAC
Sampling	48 KHz
Bitrate	64 Kbps
Channels	Stereo
Input Channel	1/2

Cancel OK

3) After setting completed, you can select corresponding audio channel for encoding when creating streaming service.

Edit NDI-HX

Type	NDIHX	* Name	NDI-HX
Audio	Channel-1	NDI Channel Name	Chan1
Group	Channel-1	Multicast IP	239.255.0.0 Generate
Connection	12	TTL	1
Net Mask	121		
Net Mask	255.255.0.0		
Server Address			


Cancel OK



6.3 Text and OSD overlay


6.3.1 Text overlay

1) Enter " OSD" — "Image management" — "Add image" .



2) Fill in "image ID in the pop up window, choose the image to upload, and then save. You can check the image and information listed under the Image list.


Fill in name in the pop-up window, select the image to upload, and then save. The image uploaded successfully will be listed under the image list.




3) Click image management back to image overlay page, click add image.



4) Go to the overlay setting pages, select image in the overlay type, and then click the image and the position you need overlay, click "Ok" .




5) The configured image overlay will be shown at the station column, check the image overlaid, and finally check image overlay to make it effect.



⚠ Note: Due to the limits of storage space, up to 10 images can be uploaded, and the maximum size of a single image is 5M. The resolution of uploaded image cannot be over the video. For the image format, only JPEG and PNG supported. You couldn't see the effects of image and text overlay in the preview window, which can be displayed on the computer by decoding output with software or decoder.

6.3.2 OSD overlay


1) Click "OSD" - "text overlay" - "add" .



2) Go to the configuration page, to choose overlay item to set overlay functions for



“Image” , “Time and Date” and “Text” respectively.




- Overlay type: “Text, Date, Time, Date/Time, and Image” for options.
- Overlay position: there are seven preset display and self-defined positions for optional, which should be based on your actual needs for selection.
- Horizontal position: when the overlay position is customized, adjust the character offset based on the horizontal offset setting.
- Vertical position: when the overlay position is customized, adjust the character offset based on the vertical offset setting.
- Font size: Three auto sizes for options. “Auto Large font” , “Auto Medium” and “Auto Small” . Adjustment from 9px to 96px also supported.
- Font style: Normal or Bold.
- Font outline: Nothing, or thickness for optional.
- Font color: Text color for optional.
- Bonder color: Text frame color for optional.




6.4 Color adjustment

1) Click color adjustment icon in the information bar page.




2) Open the color adjustment page, the system default of brightness, contrast, and saturation are all 128. Users can adjust it according to the image requirements and set the value from 0 to 255 for improving effect.



6.5 Image and rotation


6.5.1 Horizontal mirror

After clicked the horizontal mirror icon, the left and right parts of the image can be mirrored and swapped with the vertical central axis of the image as the center.



6.5.2 Vertical flip

After clicked vertical flip icon, the upper and lower parts of the image can be mirrored and swapped with the horizontal central axis of the image as the center.






6.5.3 Flip

Click spin button, you can clockwise rotate the video with 90/180/270 degrees.


6.6 Video cropping

Video source image cropping: crop a part of the original video and send it for encoding.

1) Click cropping icon in the information bar page.




2) Enter the configuration page, select the video source, click the image crop-turn on, adjust the width and height of the image, etc.





The orange area is the encoded image sent after the cropping completed. After finishing the clipping settings, the preview will be updated to show the encoded image after clipping.

3) After cropping is completed, it will be encoded according to the specific length and width pixels, and the resolution will not be changed after cropping.






6.7 Serial port and PTZ

6.7.1 USB xpansion port


With USB to RS232/RS422/RS485 adaptor (cable), after connecting to USB port, if the device and identify the serial port correctly, USB port will be listed at “Device” , then you can set the corresponding serial port parameters.



⚠️ Note: *The encoder can automatically identify the USB serial port conversion device of universal USB to Serial/FDTI chip/PL2303 chip. If the USB to RS232/RS422/RS485 converter (cable) you inserted cannot be recognized and the converter chip is not supported by default, please replace the serial cable.*


6.7.2 PTZ setting

The encoder can control the PTZ camera via Sony Visca, Pelco-D, Pelco-P protocols, you can also set the control speed.



6.7.3 Control panel

Through the web page of the encoder, you can control the movement, zoom and focus of the camera in all directions.







6.8 Local recording

S2 encoder supports local recording function. Encoder with TF card-slot can support TF recording and meanwhile it supports USB disk inserted into USB port of encoder for recording. The recording operation is as follows:

1) Click “setting” in the Web UI, click “record management” , you can see that there are video parameter display and settings in the video management column.

You can set the recording parameters, the recording is to record the main sub-bit rate at the same time, and the recording can also select the audio channel.




 **Note: A real challenge for recording by removable disks: If you remove the storage disk while recording, the recorded file may be wrong and cannot be played if the file format is '.avi' or '.mp4', etc. But 'TS' format can avoid this, also, the 'TS' format is compatible with almost all the main media players. If**



recording is performed in a non-TS format, when the recording is completed, stop the recording manually, and then remove the storage device to ensure the recording can be played normally.

- 2) By default, it automatically starts recording when storage disks inserted, regardless its storage type. It will record to the biggest available storage area. Recording format is TS file by default. Users could set recording for automatic cutting based on specified size. And when storage space is insufficient, it will automatically overwrite the old video file to achieve redundant storage.
- 3) Click storage button, you can check recording status and record list.

When no disks inserted or NAS network storage not set, the status will be as follows, dashboard will show "No Disk" .




- 4) After inserted disks, the encoder will start recording automatically and the



dashboard shows "Recording" . When it is recording, users can stop the recording manually and it can be restarted again.



5) Click storage at the top. "Video Status" is shown below, where you can view the usage of the memory or download the video files that have been stored in the memory to the computer.





6.9 NAS storage

NAS is a Disk Arrays connected by network, which has all the main characteristics of disk arrays: high capacity, high efficiency and high reliability.

Open "NAS manager" , click "add NAS" , then fill in the corresponding parameters.

The screenshot shows a dialog box titled "Add network storage" with a close button in the top right corner. The dialog contains the following fields and values:

- * ID: eqw
- * Name: eqw
- NAS Type: CIFS (dropdown menu)
- Host name: 192.168.22.35
- Volume/mount point: nas
- Mount options: user=,password=

At the bottom of the dialog, there are two buttons: "Cancel" and "OK".

ID/ Name: Any Alphabet/number

NAS Type: NFS or CIFS (CIFS is a shared protocol for network connection, which requires high reliability of network transmission, TCP/IP is usually adopted; NFS is transport-independent, TCP or UDP is adopted. One of the disadvantages of NFS is, it requires the user to install a special software, while CIFS is integrated inside the OS, and no additional software is needed.)




Host: IP address of the Host


Volume/Mount point: Storage location on the host

Mount options: Settings about the user name and password. (Use half-width commas to separate the parameters)

NAS manager will show "Mounted" , if NAS connection has been established, and there is a RECORD file under the Mount point. If the connection is abnormal, it will be displayed as "Mounting" .



A recording folder will be created by default under the folder of the mount point of the network storage server: eqw, you can go to the folder to view the corresponding recording file.






7. Streaming service

S2 encoder currently supports streaming services include: SRT/NDI|HX/RTSP/RTMP/HLS/TS-UDP. One code stream can run up to 8 stream services at the same time for the encoder, which means it can push the video stream to 8 different live platforms. There are two code streams (the main stream and sub stream) for the encoder, so the encoder can stream up to 16 different live platforms at the same time.

7.1 NDI|HX

S2 currently supports NDI|HX2, default is opening in the streaming service, click [on] to open or close NDI|HX stream service.



Click setting button in the end of stream service for stream configuration.

Name: Name for user-defined, Chinese, English and figure symbol supported.

Audio: You can choose the audio channel name set on the audio parameter page for audio encoding. The audio parameter configuration can be created by referring to chapter 6.2.3.

Group: To configure the devices to a group, the name of the group can be the combination of characters and figures. To configure multiple groups is allowed and the group names should be separated by comma (,). The default group name is




“public” . You could set a specified group name, other devices need to search this device through specified group name, which avoids being searched at will by other devices via internet.

NDI channel name: When there are multiple NDI sources in the same network, you can modify the channel name with different parameters to identify each device correctly.

Connection: Two ways of connections: unicast and multicast. Default is unicast for transmission. Unicast is for one-to-one communication between devices, while multicast is device to a group communication mode, that is to say, device that joined in the same group can receive all the data from device.

Server address: You can register the discovery of source in the discovery server. For operation steps, you can refer to the discovery server chapter.

After configured, you can discover and output through NDI connected software. You can distinguish different NDI source through device name and channel name.



7.2 NDI discovery server


The NDI discovery server can replace the NDI discovery function with a server. The NDI sources are registered to the server, then the receiving end can get the NDI




sources from the server. Or configure the function to send the output streaming to the receiving end.

Enter the NEWTEK website (<https://ndi.tv/sdk/>) on the computer serving as the server to download and install the NDI SDK. After installation, run the file:

Bin\Utilities\x64\NDI Discovery Service.exe




The NDI encoder configures the receiver IP address in the discovery server, and it will be registered to the server. It is recommended that the receiver IP address be configured as a static IP address to prevent the disconnection due to IP reassignment.



Click "discover server" on the decoder webpage to enable the function, and configure the discovery server IP address to the IP address of the computer. Then




the NDI streams are registered to the server in the receiver.



⚠ Note: After enabling the discover server, the mDNS auto-discovery function is invalid. The output streams from the encoder can only be sent to the designated server, and the receiving end must register to the same discovery server to pull the NDI streams.

7.3 RTSP


Add an RTSP stream in the encoder, if it is not decoded and there will be no additional load on the encoder. As shown in the below, if the IP address of the encoder is 192.168.2.33, then the stream address of the RTSP service is `rtsp://192.168.2.33:554/ch01`. That is, you can directly pull as many RTSP streams as IP addresses the encoder has.



Under the same LAN, you can pull RTSP streams by VLC on the computer to test





whether the encoding is normal and view parameter information, etc. After installing and enabling VLC, click "Media"- "Open Network Streaming" and fill in the URL of the encoder's RTSP service, and it can be displayed.



⚠ Note: The URL content needs to be copied completely, and the punctuation cannot be missing.

7.4 SRT

1) Click  to add a SRT stream service.



2) Fill in the pushing address and port, click "Save" . Then SRT pushing is working.



Setting parameters means the following (It can be set according to the network situation, and select the default configuration generally):

- Handshake mode: Caller, Listener and Rendezvous. The Caller and Listener mode are commonly used. In the LAN, the encoder and the decoder can use the Caller and the Listener at will. After one end uses the Caller mode, the other end uses the Listener mode. In Internet transmission, the one end with the public IP address will be the Listener;
- Public IP address: Set IP address of the receiver;
- Port: Set the listening port corresponding to the receiver;
- Transport delay: Set it based on the performance of the current network, the delay value can be set on both the SRT source device and the SRT target device. The final SRT transmission delay will be the larger one of the two values;
- SRT streaming ID: SRT streaming identification;
- Encryption mode: AES-128, AES-192, AES-256;
- AES key: Encryption key can be 10-32 letters or numbers combination;
- Bandwidth overhead: It is set as the percentage value based on network link



quality. Using this value to multiply the total bitrate of the audio and video encoded by the encoder, this will get the occupied maximum bandwidth allowed by Bandwidth Overhead. This value plus the total of video and audio bitrate is the threshold of the current SRT transmission bandwidth, and also the maximum bandwidth that SRT stream can be used. From the perspective of "overhead", it is the extra "invalid" bandwidth to be used in addition to the media content required for transmission (which can be understood as the payload), but it is different from our common protocol overhead, TCP header overhead, UDP header overhead. The bandwidth overhead here is not a fixed 20~60 bytes TCP header overhead or 8 bytes UDP header overhead. It changes in real time according to the network conditions. The worse the network link conditions are, the more overhead needs for normal transmission. The range is 5%~100%, and the default overhead is 25%;

- Load size: Sending data packet size, it is optimal that the receiver should equip with the same size. The default size is 1316, which is the optimal packet for encoding and decoding.


Network highest packet loss rate (%)	RTT Multiplier	BW Overhead	The lowest SRT delay (when RTT≤20ms)
≤1	3	33	60
≤3	4	25	80



≤7	5	20	100
≤10	6	17	120

⚠ Note: The data in the form is the reference delay value under different packet loss. When RTT > 20ms, it requires to increase the delay appropriately.

3) After configuration saved, a publishing point pushed by SRT-TS will be added, the encoder will initiate a handshake connection to the receiving end.



7.5 RTMP pushing (live streaming)

Using RTMP pushing, the first thing is to make sure platform providing RTMP pushing address, otherwise our encoders couldn't do RTMP pushing.

⚠ Note: The RTMP pushing must be pushed from the encoder to the platform. The computer/decoder then pulls the RTMP stream from the platform for playback. The encoder cannot directly push the RTMP stream to the computer/decoder for playback. While Kiloview decoders support RTMP server functions.

1) YouTube live streaming

“Streaming point” is the RTMP address given by platform (Take YouTube as an example).

Login to YouTube, get below address:




Streaming point should be like Server URL+ Stream ID/key,

For example: `rtmp://a.rtmp.youtube.com/live2/9ja6-9u28-uz4j-8x6r`

2) After getting the RTMP URL address, login to the webpage of the encoder, and click "Add a stream service" to add a stream under the "H.264 main stream" .

Select RTMP in the pop-up window and fill in the URL address into the push address (The format is: `rtmp address/live code`), and then click "OK" . If the pushing is unsuccessful, please check the network of the encoder.

3) If the video can be displayed on YouTube, the pushing is successful, otherwise please check the network and other configurations.



7.6 TS-UDP Pushing (unicast and multicast)

Click "+" to add a stream service and selects "TS-UDP pushing" .

The TS-UDP pushing includes two ways: unicast and multicast. If use unicast, the "Push Target Address" is the IP address of the device that receives the TS stream, and the "Target Port" is a port that not conflict with the ports of other services, and the "Multicast TTL" does not need to be modified. Unicast pushing can only be decoded and played at the target address; if use multicast, fill a correct multicast



address (address range: 224.xxx ~ 239.xxx) in the "Push Target Address". "Target Port" is a port that not conflict with the ports of other services. For other parameters, if there is no special requirement, it is recommended to use the default values.

⚠ Note: Multicast streams can only be decoded and played under the same network segment. Both the encoder and the player need to be configured with a gateway.

Below are some TS advanced options. if you are not sure how to set these, please just use default settings

After finishing setting, it will come up an URL address from TS-UDP pushing, which could be decoded through VLC or any other decoding player. If the multicast is decoded and played on the computer, please remember to close firewall and configure the network with a gateway.

Stream Type	Status	Name	Audio	URL	Operation
NDIHX	Streaming	NDI-HX	Channel-1		ON
RTSP	Streaming	1	Channel-1	rtsp://192.168.28.130:554/ch01	ON
SRT	Streaming	SRT	Channel-1	srt://192.168.28.130:1025	ON
UDP	Streaming	TS	Channel-1	udp://255.6.6.50000	ON




Note: When configure the multicast and get the URL is `udp://225.6.6.6:1234`. If use VLC Player to play, please insert an @ in the URL, that is, `udp://@225.6.6.6: 1234`.

7.7 HLS service

Using HLS service, the first thing is to “add a stream service” , enter streaming service interface after added correctly.

HLS service setting is very easy, if no special requirements, no need setting, only enable service after entered name and clicked ok.



Once enabling service, it will get one HLS Publish point. You could watch it through VLC and other players using this address.

Stream Type	Status	Name	Address	Operation
NDIHX	Start	NDIHX		ON
SRT	Destroy	222	offline	OFF
HLS	Start	33	http://192.168.4.89/nls/ch01/playlist.m3u8	ON
RTSP	Start	111	rtsp://192.168.4.89:558/ch01	ON



8. User Management

To add and delete users, change the password, etc.

User Managuage

Batch Deletion + Add User

<input type="checkbox"/>	User name	Alias	Create time	Operation
<input type="checkbox"/>	admin	Admin	1970-01-01 00:00:00	Edit Modify password
<input type="checkbox"/>	11	111	2020-01-06 11:43:01	Edit Modify password Deletion
<input type="checkbox"/>	22	22	2020-01-06 11:43:05	Edit Modify password Deletion
<input type="checkbox"/>	44	44	2021-08-24 15:24:31	Edit Modify password Deletion
<input type="checkbox"/>	33	33	2020-01-06 11:43:12	Edit Modify password Deletion

9. Area and Time management

Click "Location & Time" to change the time. If there are no special requirements, please select "Timing with current PC" and click "SET".

Area and time

Device time: 2021-09-01 08:54:08


Mode: Timing with current PC

Time: 2021-09-01 08:54:09

Set

Location and region

Asia/Shanghai (CST)



Change my locatoin



10. System setting

10.1 Language

Click the language window to switch the system language, currently it supports simplified Chinese, traditional Chinese and English.




10.2 Restore

If users change parameters that lead device cannot work (The typical situation is changed network address, so it cannot login to the device), users could restore factory setting to default value.

There are two ways to restore the factory settings:

- ① Webpage "Settings" > "Basic Settings" > "Restore Factory Settings";
- ② RESET button: press and hold the reset button on the bottom of the device for more than 5 seconds, the device will restore the factory settings, which will lead to a hard restart of the device, it lasts about 1 minutes.

10.3 Reboot

Click  in the upper right corner of the webpage, the device software restarts, which is equivalent to restarting the device, and it lasts about 1 minute.







10.4 Firmware upgrade

Each product is being improved, so we will continue to upgrade the functions of the device and repair BUG in the form of new version firmware. Please download it at our website "Support" - "Download center" .

Click "Basic Settings" - "Update Firmware" in the device webpage to upgrade the firmware. After uploading the firmware to the device, click "Upgrade". The upgrading will last about 2-3 minutes (depending on the size of the firmware and network conditions), and the device will automatically reboot. Remember not to power off during the upgrading, otherwise the upgrade will fail and the device will be abnormal. Please contact our support team for help if needed.



After the upgrade is completed, please check the current firmware version in the upper right corner is consistent with the latest version to ensure that the device upgrades successfully.



Note: It is recommended to use the WINDOWS system when upgrading, and use Google or Firefox to login to the device webpage.



Thank you for reading.



KILOVIEW Electronics CO., LTD.

Tel: 86-731-88315979

Website: www.kiloview.com

Technical support Email: support@kiloview.com

WhatsApp: +86-18573195156/18573195256

Address: B4-106/109, Jiahua Intelligence Valley Industrial Park, 877

Huijin Road, Yuhua District, Changsha City, Hunan Province, China